



Cast Stone Repair Mix.

This mix is for finishing off the pointing and repairs only – it is not to be used as a bedding / joint mortar

Instructions for Use:

1. The repair mix should be dry & mixed thoroughly, three parts sand & one part cement.
2. Add small amounts of the water to the dry mix until you have a 'semi dry' consistency (being able to squeeze the mix into a ball in your hand without moisture being evident on the surface).
3. Grind out the area to be repaired to a depth of 5mm staying within the original perimeters of the damaged area.
4. Mix together some water and a small amount of the mix to make a slurry paste.
5. Use low tack adhesive tape around area being pointed / repaired to avoid staining.
6. Brush the area to be repaired with the slurry, this helps act as a bonding agent but also stop the moisture been drawn out of the repair by the stone.
7. Trowel on the mix using a clean trowel (a straight edge is also a useful tool when repairing edges)

Repairs can often be obvious until time has been allowed for the mix to 'cure' & weathering has taken effect.

Repairs should not be attempted in extreme cold conditions, and should be shielded from direct sunlight in very hot conditions.

Please note: Although this method of repairing is generally accepted within the industry, it is not a substitute for the original finish. An un-damaged unit is far superior to a repaired one, no matter how good the repair is, so careful handling of cast stone is always advisable. No guarantee can be given to the accuracy of colour due to matters beyond our control i.e. the climate/weathering conditions and the accuracy/quality of the repair is entirely the responsibility of the user.

Procter Cast Stone
Isabella Road, Garforth, Leeds
LS25 2DY
+44 (0) 113 286 3329

